


# MOTOMATE


*with integrated Millenium2*



Type	Max speed	torque	Code 8
direct	3250 tr/mn	0,24 N.m	80 080 005
<i>Right angle</i>			
Rapport = 5	650 tr/mn	1,0 N.m	80 081 001
Rapport = 10	325 tr/mn	1,7 N.m	80 081 002
Rapport = 20	163 tr/mn	2,9 N.m	80 081 003
Rapport = 30	108 tr/mn	3,5 N.m	80 081 004
Rapport = 50	65 tr/mn	3,4 N.m	80 081 006
<i>planetary</i>			
Rapport = 5	650 tr/mn	1,0 N.m	80 089 704
Rapport = 27	120 tr/mn	4,5 N.m	80 089 705
Rapport = 139	23 tr/mn	20,0 N.m	80 089 706

**Software 1.3.6 :**  
**ensure that « catalog Motomate » has been installed**







Démo fct métier  
CROUZET - 1.3

MOTOMATE  
PROGRAMME

XC: MOTEUR BRUSHLESS




No real time clock reliant blocks are activated




## Movement Step (SFC)

Provides for reaching a target position with speed ramps  
The step is validated once the movement is finished




## Motor Multiplexer

Provides for grouping the « On/Off », « Direction of rotation », and « Speed » outputs of several movement steps



## Wait Step (SFC)

Provides for a time delay between two movements  
The step is validated when the given time has passed (**max. 25s!**)



## Memorisation

Provides for capturing and storing data, for example the limit positions of a mechanical system




## Memorisation position Motomate


Provides the safe storage of the position of Motomate in case of a power failure

## Block « Mémorisation position Motomate »

Counter « Motor position »



**« No parameters to be set in this function »**




**« This window is displayed by double-clicking on the function block in your program »**

**More info ? Tick here !**

Note : this specific function block only exists in the French version today

# MOTOMATE - Program example



## MOTOMATE Programming Interface

Réf. 79 294 791 SERIE  
Réf. 79 294 790 USB

