






SNAP on CLIP ASSEMBLING GUIDE

INSTALLATION



1. Center Snap on clip alongside BGA chip set.




3. Press down on other side to fasten onto the BGA chip set.

2. Tilt Snap on clip and slip one grappler under edge of BGA chip set.

4. Wiggle part to ensure good attachment.

REMOVING



1. Use a flat tip Screw driver into any of 4 holes provided on snap on clip.



2. With moderate pressure, pull back on the screw driver to dislodge clip.



3. Remove loosened Snap on clip and heat sink.



No.5, Min Lung Road, Yang Mei
Taiwan, R.O.C.
Tel : 886-3-4728155
Fax : 886-3-4725979
E-mail : sales@malico.com.tw